

ORION®

INSTRUCTION MANUAL

BODY MASSAGER
Model: OR-MS26

ENGLISH

GB



Dear Customer! Thank you for buying ORION products. Carefully read all instructions before operating and save this instruction manual for future reference.

<http://www.orion.ua>

**Dear Customer, Thank you for buying ORION products!
Welcome to use!**

IMPORTANT SAFEGUARDS

1. Before connecting the appliance check that the voltage indicated on the type plate corresponds to the mains voltage in your country.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
3. The device can not be used for treatment and instead medicine. If you are under medical supervision, consult with your physician before use.
4. Do not allow the appliance to be placed or dropped into water or any other liquid.
5. Do not reach for an appliance that has fallen into water. Turn off the power supply to the appliance and then unplug from the wall socket.
6. Do not leave the appliance unattended when it is switched on.
7. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Call the Consumer Service Centre for examination and repair.
8. It is forbidden to repair the unit. Call the Consumer Service Centre for examination and repair.
9. Do not use with wet hands.
10. Close supervision is necessary when this appliance is used by, on, or near children or invalids.
11. The appliance should be used for its intended purpose only.
12. Only for household use.
13. Never use attachments not recommended or sold by the appliance manufacturer.
14. Keep the cord away from heated surfaces.
15. Do not wrap the power cord around the appliance, straighten after use.
16. Always unplug the appliance immediately after use.
17. Do not use outdoors.
18. Do not use while in the bath.
19. Do not allow children to play with the appliance.

CAUTION!

1. Do not use if you have high temperature, heart diseases, sensitive skin, poor circulation, swelling, inflammation, or sores are present.
2. Do not use if you are experiencing unexplained pain or swollen muscles, or following a serious muscular injury before consulting your physician.
3. Discontinue use of massager if pain increases or swelling occurs after application.
4. Do not use in the presence of phlebitis and thrombosis, open and fresh wounds, bruises, broken skin or varicose veins.
5. Do not make massage on the abdomen during the period of pregnancy. See a doctor in the nearby hospital in case of stimulations and hurts.
6. The massage time after meals shall be less than one hour.
7. Massage time on the same area is suggested not to exceed 15 minutes.

PARTS



Wavy and roller attachments provide a full body massage: back, shoulders, arms, legs, hips and neck.

You can massage the body through the clothing, but the best effect is achieved while massaging a naked body.

It is best to attach the desired massage attachment when the massager is off.

Massage Attachments:

1. Wavy Massage Head
2. Roller Massage Head
3. Protecting net (is used with wavy attachment in places where hair can get into the unit)

HOW TO USE

Feature:

- relaxes and reduces tension in muscles,
- removes common sense of fatigue,
- eliminates pain neck and back,
- raises body tone,
- eliminates stress and fatigue

Use:

1. Insert the device plug into safe power socket. Ensure correct current and power.
2. Rotate the knob (start the massager and regulate the speed) to start massage
3. Rotate the knob clockwise to increase the massaging speed; rotate the knob anticlockwise to decrease the massaging speed and turn off the device.
4. Pull the plug out of the socket when finishing use of the device.
5. Ensure correct use of the protecting net to prevent the hair from being twisted.
6. Improper use of the device may hurt the hair.

Note!

- Making massage near hair use protecting net (protective cap worn over the corrugated packing).
- When using a roller attachment, you can use massage oil, body cream.
- For more effective operation of the massager is necessary to move it slowly and evenly, flowing in a circular motion or forward and back movement, without undue pressure.

CARE AND MAINTENANCE

- Switch the appliance off, unplug it and let it cool down.
- Wipe the body of the massager with a soft damp cloth. If necessary use a little washing-up liquid.
- Remove deposits from the inlet grille by brushing with a soft brush.
- Do not immerse the appliance in water or any other liquid.
- Do not use harsh or abrasive cleaning agents or solvents.

TECHNICAL CHARACTERISTICS

- Voltage: 220-240V
- Power: 15W
- Rated current: 0,07A
- Water proof: IPX0
- Net/gross weight:1025g/1100r
- Product size: 230X180X105mm
- Gift box size: 240X178X110mm
- Colour: white/purple