

Thanks for your choosing the "ORION" Twin warming mat under blanket with dual controller. To enjoy and enrich the comfort experience, please take a few minutes before starting operation of the machine and read the following operation instruction.

IMPORTANT SAFETY INSTRUCTIONS

Keep carefully in case it is needed!

This electric mattress heater is a high-quality product designed to last for many years if it is properly used and cared for. Read the following instructions carefully to prevent damage or danger from incorrect use. Keep the instructions so that you can refer back to individual points when necessary.

If you let somebody else use the blanket, you must be sure to let them have the instruction on use.

This appliance is not intended for medical use in hospitals.

- Please read carefully and follow the instructions.
- Use the device only as an electric mattress heater.
- Only connect to the voltage shown on the rating plate.
- The electric mattress heater must not be used when folded or crumpled.
- Do not use when folded.
- Do not use when crumpled.
- Do not treat the electric mattress heater as a sheet or tuck it in under the mattress.
- Do not use the blanket for persons who cannot move without help, small children, persons who cannot feel heat, or animals. Persons who can feel heat to some extent may only use the blanket with supervision.
- Do not prick it with needles or other sharp objects.
- Do not tug or twist the power lead.
- Do not expose the switch or power lead to moisture or liquids.
- If the cord is damaged, it must be replaced by the manufacturer or similar qualified persons in order to avoid a hazard.
- Do not use the electric mattress heater when it is damp or wet.
- The device may not be switched on using a time switch.
- Avoid folding the blanket tightly.
- While the blanket is switched on,
 - Do not place any large or heavy objects on it such as suitcases, etc.,
 - Do not place any source of heat on it such as hot water bottles, heating pads or such like
 - Do not allow the switch to be concealed under blankets, pillows or the like and lie on the electric mattress heater.
- Do not fold the blanket when hot.
- Please check the blanket and power lead frequently to look for signs of wear or damage. If you find evidence of wear or a defect, or the blanket has been used incorrectly, return it to us for checking and any necessary repairs.
- If you do not use the blanket daily, remove the plug from the socket and take the blanket off your bed. Keep it dry until it is taken out for use again – the original bag is an ideal place to store it.
- The setting of the control unit for all night use.
- Do not use on an adjustable bed or if used on an adjustable bed, check that the blanket or cord cannot become trapped or rucked.
- This blanket is not to be used by young children unless the controls have been preset by a parent or guardian or the child has been instructed and how to operate safely.
- **When storing the appliance, allow it to cool down before folding.**
- **Do not crease the appliance by placing items on top of it during storage.**



SWITCHING ON

1. Spread the blanket out flat on the mattress ensuring there are no folds with the lower edge is at the bottom of the bed and the power lead towards the head end. Then lay a sheet over it. take care not to allow any folds or kinds to develop where mattress sections abut. Each time the blanket is used please check that it is spread absolutely flat on the mattress. Then place a blanket or duvet on top of the electric mattress heater and covering sheet to prevent loss of heat.
2. Push the flat plug of the blanket into the socket.

The blanket may only be used with 220-240 Volts a.c.
Switch on the blanket using the hand-operated switch.

3 = maximum warmth, warm-up time approx. 30 minutes. The indicator light will keep on and won't flash

2 = moderate warmth, the indicator light will flash

1 = minimum warmth, the indicator light will weak flash (setting 1 is recommended for all night use.)

0 = OFF, the blanket is disconnected from the power supply.

The indicator light lights up during the heating phase: now you can experience the pleasant warmth. After about 120 minutes the blanket silently switches off automatically.



ADDITIONAL NOTE:

The electronic components inside the switch may lead to a slight warming of the switch when the blanket is on. Therefore the switch must not be covered or placed on top of the electric mattress heater when it is in operation.

You should not rely on using your hands to gauge the blanket's temperature because they are much less sensitive to heat than the surface of the human body. A temperature, which may feel tepid to your hand, may feel unpleasantly hot on your body.

The blanket must be covered by a duvet, for example, because otherwise there will be a high loss of heat and the blanket cannot warm up properly.

Qualified persons using original replacement parts may only undertake repairs to the electric mattress heater. Repairs carried out by unqualified persons may cause substantial risk to the user.

CLEANING AND CARE

The electric mattress heaters should be kept clean because it must not be laundered or dry-cleaned.

Small stains can be removed with a cloth or a damp sponge, perhaps using some mild liquid detergent. Before cleaning the blanket, always remove the plug from the power socket. The blanket must not become wet. If it gets damp it needs natural drying in the air.

Never switch on the blanket to dry it.

RETAIN FOR FUTURE USE

Examine the appliance frequently for signs of wear or damage. If there are such signs or if the appliance has been misused, return it to the supplier prior to any further use.

TECHNICAL DATA:

Model: ORION OWP10UBT

Size: 150 (L) * 140 (W) cm

Material: Polyester

Voltage: 220V-240V~ 50Hz

Watts: 60W max. for individual control

Net weight: 1,5kg

AC cord length: 2,6m

Color: white