

ORION®

INSTRUCTION MANUAL

CERAMIC FAN HEATER

ENGLISH

GB

Model: OR-FH15C



220V-240V 50Hz 750W/1500W



DEAR CUSTOMERS!
MANY THANKS FOR BUYING ORION CERAMIC FAN HEATER!

We really believe you will get the greatest pleasure from using this device for the years!

Please, read the user's guide in detail before first using of this ceramic fan heater.


GENERAL SAFETY INFORMATION

1. Read all instructions before using the Heater.
2. Use this Heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electrical shock, or injury to person.
3. Make certain that the power source conforms to the electrical requirements of the Heater.
4. Use the heater on flat surfaces, not inclining from the horizontal or vertical, don't use underneath socket directly.
5. Do not use your heater in the presence of explosive or flammable substance.
6. Do not use same socket with other high power electrical appliances at same time when heater is working.
7. There should be tight connection between plug and socket so as to avoid the overheating plug and malfunction.
8. Unplug the heater by grasping plug and pulling it from the socket. Never yank the power cord.
9. Pay attention when using heaters in presence of children, old man, and disabled people. No use when no supervision.
10. To avoid danger please return the heater to the approved service agent for changing when power cord damaged.
11. Do not use the appliance near hot surfaces.
12. Ensure all times that the unit is placed solidly on its base. Make sure that the air inlet and outlet openings are not blocked. To avoid any risk of fire, do not cover the heater. (Ex. with clothes).
13. Do not insert any objects through the grille into the interior of the appliance.
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should supervised to ensure that they do not play with the appliance
15. The heater should only be operated at minimum distance of 50cm from any wall or other object. Position the air flow in order to optimize the heating of the room. Avoid corners, small volumes, floors and ceilings.

WARNING: TO AVOID DANGER OF ELECTRICAL SHOCK, UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING. IF THE SUPPLY CORD IS DAMAGED, IT MUST BE REPLACE BY A SPECIAL CORD OR ASSEMBLY AVAILABLE FROM THE MANUFACTURE OR ITS SERVICE AGENT. SAVE THESE INSTRUCTION FOR FUTURE REFERENCE

PARTS NAME

1. Pilot lamp
2. Thermostat
3. Swing button
4. Rotary switch
5. Outlet wind
6. Base



OPERATING INSTRUCTIONS

1. Remove the Heater from the carton.
2. Place the heater on a firm level surface.
3. Set the main power to 'Off'. Plug the cord set into a 220V electrical outlet.
4. The heater is equipped with 4-position rotary switch:

SYMBOL	FUNCTION
0	OFF
*	Fan without heater
I	750W (Low heat output)
II	1500W(Full heat output)

5. Set the rotary switch to maximum for fast warm up of a room. Once the temperature of room is comfortable, select a lower setting to reduce electrical consumption and to prevent the room from becoming too warm.
6. If you selected low or full output, choose the desired temperature with the thermostat. With the Thermostat, the temperature can be regulated step by step.
7. When the desired temperature is reached, the unit will automatically switch off. Once the temperature has fallen below the pre-set level, the heater will switch on again.
8. Pilot light will allow you to check the thermostatic regulation. When the appliance is heating, this pilot light will be on. It will go out when the desired temperature is reached.
9. Before removing the plug from the socket, switching off and better work for 30-60 seconds with cool air in condition that protecting inner parts.

SWING BUTTON

This appliance also has the swing function. To switch the function on, press the swing switch. To stop it, press the swing switch again.

OVERHEAT/TIP-OVER PROTECTION

“Overheat protection”

This heater is protected with an overheat protection that switches off the appliance automatically in case of overheat, e.g. due to the total or partial obstruction of the grids. In this case, unplug the appliance, wait about 30 minutes for it to cool and remove the object which is obstructing the grids. Then switch it back on as described above. The appliance should operate normally. Should the problem persist, please contact the nearest customer service.

«Tip-over protection»

This heater is protected with a safety switch that turns off the appliance automatically when the heater falls over, or is at an excessive angle from the horizontal. This helps prevent accidents, and the heater will resume operation when it is put back upright.

CLEANING AND MAINTENANCE

WARNING: ALWAYS UNPLUG THE CORD BEFORE MOVING OR SERVICING.

CLEANING: IMPORTANT! DO NOT IMMERSE HEATER IN WATER!

Wipe exterior surfaces of the heater with a moistened cloth.

DO NOT ATTEMPT TO TAKE APART HEATER. DO NOT REMOVE GRILL.

CAUTION: Do not use gasoline benzene, thinner, harsh cleaners, etc. as they will damage the Heater.

STORAGE: Store the Heater with these instructions in the original carton in a cool, dry place.

SPECIFICATIONS

CERAMIC FAN HEATER

ORION OR-FH15C

3 work settings

Cool/Warm/Hot wind for selection

Swing function 70°

Adjustable thermostat control

Tip-over protection

Overheat protection

Power indicator light

Functional handle for easier mobility

Power: 20W/750W/1500W

Voltage: 220-240V~50Hz

Net/ Gross weight: 2,3kg/2,66kg

Body size: 185x160x422mm

Box size: 210x180x455mm



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact

the retailer where the product was purchased. They can take this product for environmental safe recycling.

Extra information on ORION company web-site www.orion.ua

We take your opinion and offers by E-mail support@orion.ua