

INSTRUCTION MANUAL

STEAMING CENTRE 4 in 1



ORION OB02

CAREFULLY READ ALL INSTRUCTIONS BEFORE OPERATING AND SAVE FOR FUTURE REFERENCE

AC230V~50Hz, 300W



Dear Customer, Thank you for buying ORION products! Welcome to use!

Every day parents make choices to ensure the best for their children. Choosing bottle/food warmer ORION OB02 – is the best choice! This product is a guarantee of quality and safety for your child! It has been designed to make your life as a parent a little easier. ORION OB02 is a sterilizer, bottle warmer and steam cooker in one space saving device. Temperature control system meets the most stringent safety standarts.We guarantee the quality and safety of this product!

Please read this User's Guide carefully before usind the appliance and save it.

IMPORTANT PRECAUTIONS

WARNING! YOU ARE FULLY RESPONSIBLE FOR YOUR OWN SAFETY WHILE USING THIS APPLIANCE

- Check if the voltage that is indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- If the mains cord is damaged, it must be replaced by an authorised service centre or similarly qualifed persons in order to avoid a hazard.
- Do not expose the appliance to extreme heat or direct sunlight.
- Never disassemble the base to avoid the risk of electric shock.
- Never operate the device without water in it.
- Only use pure tap water without any additives.
- Do not put bleach, descaling agents or other chemicals in the appliance.
- Do not immerse the base, the cord or the plug in water or any other liquid.
- Always let the appliance cool down before moving or storing it.
- The appliance becomes extremely hot when it is in use and may cause burns if it is touched.
- Always lift the lid, the cap and the cover by their handle.
- Beware of hot steam that comes out of the vent in the cover when the appliance is in use without the cap. Steam can cause burns.
- Never move or open the appliance when it is in use or when the water in it is still hot.
- Always place and use the appliance on a dry, stable, level and horizontal surface.
- Do not place the appliance on a hot surface or in a heated oven.
- Keep the appliance out of the reach of children.
- Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- Only use baby bottles that have been approved for boiling.
- Always pour any remaining water out of the appliance after use.
- Test food on the back of your hand before serving it, to ensure that it is at a safe temperature for your baby.
- Always unplug the appliance after use.
- Never place items on top of the appliance when it is in use.
- Unplug the baby bottle food warmer when not in use.
- Do not dismantle it by yourself, baby bottle/ food warmer does not contain any user serviceable part inside.
- Do not heat food continuously, it may destroy the vitamins of the food.

WARNING! OBSERVE SAFETY RULES TO AVOID THE RISK OF ELECTRIC SHOCK AND FIRE.

DELIVERY SET

1.	Steamer 1	
	a) Lid 1	pc.
		pc.
	c) Container 1	pc.
	d) Base 1	
	e) Cap	pc.
	f) Dome 1	
	g) Bowl	рс.
	h) Measuring cup 1	pc.
	i) Tongs 1	рс.
2.	Instruction manual1	pc.
3.	Warranty card 1	
4.	Information card ORION1	
5.	Packing box 1	•


FEATURES


Steamer with functions of warming	ORION OB02
and sterilization 4 in 1:	
Power supply:	AC230V~50 Hz
Power consumption:	300W
Rated current:	1,3A
Electric shock protection class:	II
Humidity protection degree:	IPX0
Color:	white/green
Box size:	230x230x310mm
Product size:	250x195x65mm
Net/gross weight:	0,6kg/0,65kg
Sterilization	
Quick and safe food/bottle warming	
Temperature maintenance	
Steam cooking	
Electronic control with LCD	
Modern design	
Easy-to-use and safe, easy to clean	

CONTROL PANEL



DESCRIPTION









- 1. Lid
- 2. Basket
- 3. Container
- 4. Base
- 5. Cap
- 6. Dome
- 7. Bowl
- 8. Measuring cup
- 9. Tongs

BEFORE FIRST USING

- 1. Check if the voltage that is indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- 2. Unpack the appliance.
- 3. Wash all the parts of the appliance (except the base) in warm soap water before first using. Rinse and dry all parts.
- 4. Clean the base with damp cloth.

HOW TO USE

- 1. Place the appliance on a dry, stable, level and horizontal surface.
- 2. Plug the unit into the socket and press the ON/OFF button. All the function indicators will flash once accompanied by a double beep and the display will show the ambient temperature. Press ON/OFF again and the unit will beep once and switch off automatically.
- 3. After switching on the appliance choose the desired function and follow the instructions below.
- 4. Setting the temperature: the temperature may be adjusted while the device is working with the + and buttons. Press once to increase/decrease by 1° (minimum temperature 37°C maximum temperature 100°C).

FUNCTIONS

Bottle/jar warmer

- 1. Using the measuring cup, fill the base tank (4) with 150 ml water.
- 2. Remove the cap (5) and place the dome (6) on the base tank (4).
- 3. Place the bottle (or jar) in the base, inside the dome.
- 4. Press the "bottle warmer" button. The device beeps once and the indicator light illuminates. The default temperature of 40°C appears on the display and flashes 4 times.
- 5. Once the temperature reaches 40°C, the device beeps three times in succession. The Indicator light turns green and the "bottle warmer" function stops. After eight hours, the "warmer" function stops and the device beeps for a minute.
- 6. Do not keep food warm for prolonged periods.
- 7. Always unplug the appliance after use.



Warmer

- 1. Using the measuring cup, fill the base tank (4) with 150 ml water.
- 2. Remove the cap (5) and place the dome (6) on the base tank (4).
- 3. Place the bottle (or jar) in the base, inside the dome.

- 4. Press the "keep warm" button. The device beeps once and the indicator light illuminates. The default temperature of 50°C appears on the display and flashes 4 times.
- 5. Once the temperature reaches 50°C, the device beeps three times In succession. The Indicator light turns green and the "warmer" function stops. After eight hours, the "warmer" function stops and the device beeps for a minute.
- 6. Always unplug the appliance after use.

WARNING! Before giving milk to a child, pour a few drops onto the back of your hand to check the temperature.

Steam cooking

Steamed fruits and vegetables are the perfect foods for a baby from 4-6 months on. Steam cooking is the healthiest way to prepare food. Steamed food maintains more vitamins and more healthy nutrients. ORION OB02 can steam 50 to 150 grams of any type of fruit or vegetable. Cooking time depends on the quantity, type and starting temperature of the ingredients.

- 1. Using the measuring cup, fill the base tank (4) with 80-90 ml water.
- 2. Place up to 150 g of fruit or vegetables cut into small pieces in the bowl (7).
- 3. Put the bowl on the base and cover with the dome (6).
- 4. Press the "steam cooking" button. The device beeps once and the indicator light illuminates. The default temperature of 100° C appears on display and flashes 4 times.
- 5. When the temperature reaches 100°C and the water evaporates completely the device beeps three times in succession. The green indicator light flashes three times. The "steamer" function stops and the food is ready to be eaten.
- 6. Always unplug the appliance after use.

Avoid contact with steam escaping from the cap and dome as it is very hot!



Sterilization

- 1. Using the measuring cup, fill the base tank (4) with 40ml water.
- 2. Place the container (3) on the base (4).
- 3. Place bottles (no more than 7) in the sterilizer. Place the bottles upside down in the special container. This allows steam to enter the bottle freely. To sterilise teats, lids and small toys, place the basket (2) in the upper part of the container. Cover the container with the lid (1).
- 4. Press the "sterilizer" button. The device beeps once and the indicator light illuminates. The default temperature of 100°C appears on the display and flashes 4 times

- 5. When the temperature reaches 100°C and the water evaporates completely the device beeps three times in succession. The green indicator light flashes three times. The sterilization process is now complete.
- 6. Always unplug the appliance after use.



Notes:

- 7 standart bottles can be placed into the container.
- Bottles and accessories must be washed, rinsed with cold water and drained before sterilising.
- Wait at least 30 minutes between sterilising cycles.
- To prevent the risk of scalding, remove hot bottles and accessories using the tongs provided.

CLEANING

- 1. Always unplug the appliance and let it cool down before you clean it.
- 2. Clean the base with a moist cloth. All the other parts wash in warm soap water.
- 3. Do not use the abrasives.
- 4. Never immerse the base in water.
- 5. To clean the base from scale use 150 ml of 50% solution of vinegar in water. Leave the solution to act untill all the scale has been removed. Drain any residual liquid with a damp cloth and dry.

Note:

• We recommend to clean the appliance from scale once a month.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

MANUFACTURING DATE - 15/01/2011 DEVELOPED BY ORION ELECTRONICS LTD (29 Jászberényi út, Budapest 1106, HUNGARY, EUROPE) ASSEMBLED IN P.R.C. UNDER STRICT CONTROL OF ORION ELECTRONICS LTD (HUNGARY, EUROPE) CERTIFIED AND APPROVED BY ORION ELECTRONICS LTD (HUNGARY, EUROPE)

> Extra information on ORION company web-site <u>www.orion.ua</u> We take your opinion and offers by E-mail <u>support@orion.ua</u>